



Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli


XX = AA, AD,

- 1 - B 961564 XX
- 3 - B 964696 NU
- 4 - B 964697 XX
- 5 - B 964698 NU
- 6 - B 961478 NU
- 8 - B 961202 XX
- 8a - B 960962 XX
- 9 - B 960497 NU
- 10 - B 960839 NU
- 11 - B 960712 XX
- 12 - B 964702 NU
- 14 - A 963600 NU




ALPHA

03.2019 / B665960




B C660 ..





B C650 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>





| | | | | | | | |
|--|---|-----|-----|---------|----|--|-----------|
| | P | bar | 0,5 | MAX. 10 | 5 | | Q (3 bar) |
| | T | °C | | MAX. 80 | 65 | | l/min |
| | | | | | 40 | | 9 |

